

F1G. 2

DATA
VARIOUS HEADER INFORMATION
PACKET LENGTH
STREAM SUB-TYPE PACKET ID LENGTH
STREAM ID
CHAPTER I D
PROGRAM I D
START CODE

FIG. 3




FIG. 4




FIG. 5




FIG. 6

		Τ'								,							
0	661	CHAPTER END ADDRESS	0×00-1000-0000	0000-0087-00x0	0x00-3A00-0000		XXXX	0000-0081-00x0	0×00-5D0-0000		XXXX	0000-0001-00x0	0×00-3100-0000		XXXX		0xFF-F000-0000
START RECORD SEQUENCE NUMBER	END RECORD SEQUENCE NUMBER	CHAPTER START ADDRESS	0×00-0000-00×0	0x00-1005-0000	00h05m00s 0x00-2600-0000	•	XXXX	0×00-0003-0000	0x00-1F00-0000	• •	XXXX	0×00-0000-00×0	0×00-2000-0000	•	XXXX		XXXX
000	000	CHAPTER TIME	00h05m00s	00h05m00s	00h05m00s	•	00h02m30s	00h05m00s	00h05m00s	•	00h05m00s	00h05m00s	00h05m00s	•	00h01m42s		00h04m00s
0000-0000-00×0	0xFF-F000-0000	RECORD SEQUENCE NUMBER	0	3	9		19	ļ	4		15	2	9		29	:	199
0	0	CHAPTER 1D	0	-	2		2	0	1		4	0	1		11		0
ESS	EA SS	PROGRAM TIME	00h27m30s					00h23m25s			:	00h56m42s					00h04m00s
RECORD AREA START ADDRESS	RECORD AREA END ADDRESS	PROGRAM I D	0		٠			1				2		-			25
RI ST,	~ ~ ~	PROGRAM NAME	PROGRAM A					PROGRAM B				PROGRAM C		-			PROGRAM X

FIG. 7

	0	200	CHAPTER END ADDRESS	0x00-2300-0000	0x00-3A00-0000		XXXX	0x00-1800-0000	0x00-2D0-0000		XXXX	0x00-1D00-0000	0x00-3100-0000		XXXX		0xFF-F000-0000	0x00-0001-0000 (RECORDING CONTINUES)
	START RECORD SEQUENCE NUMBER	END RECORD SEQUENCE NUMBER	CHAPTER START ADDRESS	0x00-1005-0000	0×00-2600-0000	•	XXXX	0000-8000-00×0	0x00-1F00-0000	•	XXXX	0000-0000-00×0	0×00-2000-0000	•	XXXX		XXXX	0xFF-F000-0000
ROGRAM Y)	000	000	CHAPTER	00h05m00s	00h05m00s	•	00h02m30s	00h05m00s	00h05m00s	•	00h05m00s	00h05m00s	00h05m00s	•	00h01m42s		00h04m00s	00h02m51s
RDING OF P	0×00-0003-0000	0×00-0001-0000	RECORD SEQUENCE NUMBER	3	9		61	ı	4		12	7	9		53	•	199	200
TING RECO	0	0	CHAPTER ID	1	2		5	0	1		4	0	1		11		0	0
(DELETING PROGRAM AO, AND STARTING RECORDING OF PROGRAM Y)	ESS	SS	PROGRAM TIME	00h27m30s				00h23m25s				00h56m42s					00h04m00s	00h02m51s
PROGRAM	RECORD AREA START ADDRESS	RECORD AREA END ADDRESS	PROGRAM I D	0				l				2					52	26
( DELETING	RI ST,	≅ <u></u>	PROGRAM NAME	PROGRAM A				PROGRAM B				PROGRAM C					PROGRAM X	PROGRAM Y

FIG. 8

RECORD AREA START ADDRESS RECORD AREA END ADDRESS PROGRAM PROGRAM PROGRAM A 0 00H PROGRAM B 1 00H	REA RES ESS M PROGRAM TIME 00h27m30s	0 CHAPTER 10 2 2 2 5	0x00-000C-0000 0x00-0006-0000 SEQUENCE NUMBER 3 00 3 00 6 00 4 00	000 CHAPTER TIME 00h05m00s 00h05m00s 00h05m00s	START RECORD SEQUENCE NUMBER END RECORD SEQUENCE NUMBER CHAPTER START ADDRESS 0x00-1005-0000 0x00-1005-0000 xxxx 0x00-1F00-0000	2 201 201 CHAPTER END ADDRESS 0x00-2300-0000 0x00-3400-0000
	00h23m25s	4	15		0x00-1F00-0000 · · xxxx	
	00h56m42s	1	9	00h05m00s 00h05m00s	0x00-0000-0000 0x00-2000-0000	0x00-1D00-0000
		=	29	00h01m42s	XXXX	XXXX
25	00h04m00s	0	199	00h04m00s	XXXX	0×FF-F000-0000
56	00h07m11s	0	200	00h05m00s	0xFF-F000-0000	0x00-0001-0000
		1	201	00h02m11s	0×00-0001-0000	0x00-0006-0000 (CHAPTER DIVISION IS PERFORMED AND RECORDING CONTINUES

FIG. 9

(DELETING PROGRAM CO, AND RECORDING OF PROGRAM Y ENDS)

3	201	CHAPTER END ADDRESS	0x00-2300-0000	0x00-3A00-0000		XXXX	0x00-2D0-0000		XXXX	0×00-3100-0000		XXXX		0xFF-F000-0000	0×00-0001-0000	0x00-F000-0000	(RECORDING ENDS)
START RECORD SEQUENCE NUMBER	END RECORD SEQUENCE NUMBER	CHAPTER START ADDRESS	0×00-1005-0000	0x00-2600-0000	•	xxxx	0x00-1F00-0000	• •	XXXX	0×00-2000-0000	•	XXXX		XXXX	0xFF-F000-0000	0x00-0001-0000	
000	000	CHAPTER TIME	00h05m00s	00h05m00s	•	00h02m30s	00h05m00s	•	s00m30400	00h05m00s	•	00h01m42s		00h04m00s	00h05m00s	00h04m20s	
0×00-1005-0000	0×00-F000-0000	RECORD SEQUENCE NUMBER	3	9		19	4		15	9		29	•	199	200	201	
0	0	CHAPTER ID	l	2		2	1		7	ı		11		0	0	_	
A SS	EA SS	PROGRAM TIME	00h27m30s				00h23m25s			00h56m42s	-			00h04m00s	00h09m20s		
RECORD AREA START ADDRESS	RECORD AREA END ADDRESS	PROGRAM 1D	0				J			2				25	26		
R ST.	る団	PROGRAM NAME	PROGRAM A				PROGRAM B			PROGRAM C				PROGRAM X	PROGRAM Y		




FIG.11

					· · · · · ·					
PROGRAM ID	STREAM ID	SUB TYPE	CHAPTER ID	STREAM START ADDRESS	STREAM END ADDRESS					
		<u> </u>								
O (PROGRAM A)	0xE0 (VIDE01)	0x00	0	0x00-0000-0000	0x00-1000-0000					
(FRUGRAM A)	(VIDEOI)		1	0x00-1005-0000	0x00-2300-0000					
			2	0x00-2600-0000	0x00-3A00-0000					
				• • •						
	0xC0	0x00	0	0x00-0000-8000	0x00-0FFC-0000					
	(AUD   01)		1	0x00-1005-8000	0x00-22FC-0000					
			2	0x00-2600-8000	0x00-30FC-0000					
1	0xE0	0x00	0	0x00-0003-0000	0x00-1800-0000					
(PROGRAM B)	(VIDEO1)		1	XXXX	XXXX					
	0xC0	0x10	0	xxxx	xxxx					
	(AUD   01)	(MAIN AUDIO)	1	XXXX	XXXX					
	0xC1	0x11	0	XXXX	xxxx					
	(AUD 102)	(SUB AUDIO)	1	XXXX	XXXX					
2	0xE0	0x00	0	0x00-0C00-0000	0x00-1D00-0000					
(PROGRAM C)	(VIDEO1)		1	XXXX	XXXX					
			•••							
	0xC0	0x21	0	xxxx	xxxx					
	(AUD I 01)	(JAPANESE)	1	xxxx	XXXX					
	0xC1	0x20	0	XXXX	xxxx					
	(AUD102)	(ENGLISH)	1	XXXX	XXXX					
					· · · · · · · · · · · · · · · · · · ·					
	0xBD	0x00	0	xxxx	xxxx					
	(DATA)		1	XXXX	XXXX					
					<u> </u>					
		- <del>!</del>								